Upgrade kit

for Wooden pole set **Adventure Nordic tipis**





Follow the original manual, but apply following changes.

Replace the the wing screws in the top joint with the new screws.

Drill a 6 mm hole for the new screw, through the top of each main pole.

Mount the wood poles into the sockets and tighten the screw all the way

Use straps together with the wire to pull the cross poles together. The straps may need to be tightened again after some time.





