

Cleaning Adventure tipis (lightweight fabric)



Tentipi recommend using NIKWAX Tent & Gear Solarwash for cleaning our lightweight tipis and it also protects against UV deterioration. Use gloves when cleaning.

1. Limit the work area so you treat one part at a time. Place the part of the tent that is to be cleaned on a flat surface. With larger Nordic tipis, it is best to take one panel at a time.
2. Spray evenly to outside of fabric. Use approximately 50 ml of product per 1 m² of fabric, depending on the condition of the fabric being treated.
3. Rub in well with a damp cloth/sponge, paying attention to dirty areas.
4. Rinse with clean water using a cloth or sponge.
5. Allow the tent to be air dried. Before packing away, make sure the tent is fully dried.

Cleaning Adventure tipis (cotton/polyester fabric)



Tentipi recommend that stains on the canvas are removed using warm water and possibly yellow or green soft soap ("såpa"). If the canvas is cleaned with other agents than lukewarm water, the original impregnation will be removed and the tent canvas will have to be re-impregnated. Allow the tent to be air dried. Before packing away, make sure the tent is fully dried.

Instructions for how to impregnate Adventure tipis of cotton/polyester fabric with NIKWAX Cotton Proof

1. Limit the work area so you treat one part at a time. Place the clean part of the tent canvas that is to be impregnated on a flat surface. With larger Nordic tipis, it is best to take one panel at a time.
2. Dilute the agent as stated in the guide below. Lukewarm water must be used for diluting NIKWAX Cotton Proof.
3. For the best results, the area to be treated should be damp since this will help the impregnating agent to penetrate the fabric. Apply the diluted impregnating agent evenly on the outside of the canvas. Use a good-quality cellulose sponge and work the impregnating agent into the canvas.
4. Make sure there are no areas that have been missed.
5. After a few minutes, wipe off excess agent using a damp towel. This will prevent any patches from forming.
6. Allow the tent to be air dried. Before packing away, make sure the tent is fully dried.

Recommended amount of NIKWAX agent diluted with lukewarm water:

Size	NIKWAX (ml)	Water (litre)
Adventure 5	200	1.6
Adventure 7	300	2.5
Adventure 9	450	3.8
Adventure 15	600	5



Cleaning Event tipis



Tentipi recommend that stains on the canvas are removed using warm water and possibly yellow or green soft soap ("såpa"). If the canvas is cleaned with other agents than lukewarm water, the original impregnation will be removed and the tent canvas will have to be re-impregnated. Allow the tent to be air dried. Before packing away, make sure the tent is fully dried.

Instructions for how to impregnate Event tipis with Herdins Imprenex

1. The tent should be cleaned before impregnation. Use water together with a mild soap ("såpa") solution (bile soap can be used if diluted with water). Rinse the tent well and let it dry. Avoid washing and impregnation in strong sunshine.
2. Use a paintbrush, a brush or a cellulose sponge to work Imprenex into the canvas. The tent has to be dry and for best results let the temperature be + 10° C during impregnation.
3. Let the impregnation dry in heat, but avoid strong sunshine. This will prevent any patches from forming.
4. Make sure there are no areas that have been missed.
5. After a few minutes, wipe off excess agent using a damp towel. This will prevent any patches from forming.
6. Allow the tent to be air dried. Before packing away, make sure the tent is fully dried.

Recommended amount of Imprenex agent used undiluted:

Size	Imprenex (litre)
Cirrus 20	12.5
Cirrus 28	16
Cirrus 40	22
Cirrus 72	36
Stratus 72	38

