

Central pole

Handle your central pole with care. Stretch the ground straps equally around the tent; 15 kilos of strain on each ground strap is sufficient. Over-stretching may cause the central pole to bend.

If for some reason, the central pole has become bent, it must not be used. A bend on the pole means the pole has been weakened and this may lead to the pole breaking and the Nordic tipi collapsing. If this should happen when a fire or stove is in use inside the tent, this could cause great damage and people could be seriously injured.

If you have left your central pole at home, you can use any wooden pole/stick instead. (Ask the landowner's permission first).

The exact measurements for the different sizes are:

Size 5: length 2250 mm.

Size 7: length 2720 mm.

Size 9: length 3100 mm.

Size 15: length 3600 mm.